

HIACE

Description	Short Model Code	Model Name
BUSH SUB-ASSY LWR	"KDH205, TRH229"	Hiace
GROMET	EE80R/ KDH200R/ WU95R	Hiace
CONTROL ASSY BACK	GDH201,KDH2**,LH2**,TRH2*	Hiace
SHAFT ASSY STEERING	GDH201R/KDH223R/LH222R/TRH223R	Hiace
ABSORBER ASSY	GDH322	Hiace
ABSORBER SHOCK RR	GDH322	Hiace
STEP SUB-ASSY BACK	KDH2#	Hiace
ECU	KDH2###/TRH2##	Hiace
CAP SUB-ASSY WHEEL	KDH200	Hiace
ARM FR WIPER RH	KDH200	Hiace
HEAD SUB-ASSY	KDH200R	Hiace
TUBE SUB-ASSY FUEL	KDH200R	Hiace
LENS BODY RR	KDH200R, H212R, TRH223R	Hiace
RESERVOIR ASSY	KDH200R, KDH222R, TRH223R	Hiace
SHROUD FAN NO.1	KDH200R/ KDH212R/ LH200R	Hiace
SENSOR SPEED FR LH	KDH200R/ KDH223R/ TRH223R	Hiace
ELBOW COMPRESSOR	KDH200R/KDH212R/KDH222R	Hiace
FITTING KIT, DISC	KDH202	Hiace
LINK ASSY POWER	KDH202	Hiace
BRACKET STABILIZER	KDH202	Hiace
STOPPER SUB-ASSY	KDH202	Hiace
COMPRESSOR ASSY	KDH202	Hiace
NUT	KDH202	Hiace
SEAT	KDH202R	Hiace
BRACKET STABILIZER	KDH205	Hiace
BOOT KIT, FR DRIVE	KDH206K/TRH226K/KDY281	Hiace
WHEEL DISC	KDH212	Hiace
LINK ASSY POWER	KDH212	Hiace
ARM SUB-ASSY	KDH212	Hiace
SENSOR SPEED RR LH	KDH212R/KDH223R/TRH223R	Hiace
SWITCH HAZARD	KDH220R	Hiace
BUMPER RR SPRING	KDH222	Hiace
SENSOR SPEED FR RH	KDH222	Hiace
MOTOR COOLING FAN	KDH222R	Hiace
CAP KNUCKLE GREASE	KDH222R	Hiace
ACTUATOR ASSY BRAKE	KDH222R	Hiace
BLOCK ASSY DRIVER	KDH222R/TRH223R	Hiace
COVER RR BUMPER	KDH223R/LH222R/TRH223R	Hiace
HOSE FLEXIBLE	KDH223R/LH222R/TRH223R	Hiace
PLATE SUB-ASSY	KDH223R/TRH223R	Hiace
CABLE SUB-ASSY FUEL	KDH223R/TRH223R	Hiace
CASE SUB-ASSY	KDH223R/TRH223R	Hiace
BOOT KIT,FR DRIVE	KLH18/ KLH28/ RCH29	Hiace
MOTOR COOLING FAN	TRH223R, KDH223R, KDH200R	Hiace
HOUSING SUB-ASSY	TRH223R, KDH223R, KDY251R	Hiace
COVER FR BUMPER	TRH223R/KDH223R	Hiace

COVER FR BUMPER	TRH223R/TRH200/KDH220R	Hiace
GRILLE RADIATOR	TRH223R/TRH200/KDH220R	Hiace

